



# DVPlayer

17:15:18 33 KM/H N:50.15889 E:14.35592





Playlist

File Name
M9G25K_20201012161457_000083F.MP4
M9G25K_20201012161757_000084F.MP4
M9G25K_20201012162057_000085F.MP4
M9G25K_20201012162357_000086F.MP4
M9G25K_20201012162657_000087F.MP4
M9G25K_20201012162957_000088F.MP4
M9G25K_20201012163257_000089F.MP4
M9G25K_20201012163557_000090F.MP4
M9G25K_20201012163857_000091F.MP4
M9G25K_20201012164157_000092F.MP4
M9G25K_20201012164457_000093F.MP4
M9G25K_20201012164757_000094F.MP4
M9G25K_20201012165057_000095F.MP4
M9G25K_20201013073658_000096F.MP4
M9G25K_20201013073959_000097F.MP4
M9G25K_20201013074258_000098F.MP4
M9G25K_20201013074558_000099F.MP4
M9G25K_20201013074858_000100F.MP4

# DVPlayer instructions

1. After downloading the installer, follow the installation instructions.
2. Start DVPlayer
3. The first time you start the video you need to fill in your registration number and email => click on "Enter Registration Code"



#### 4. The registration number can be found on the front of the manual

The image shows a computer screen with the DVPlayer application running. A registration dialog box is open, asking for a registration code and email. A red arrow points from the registration number 'SYZNU95Q3S' in the TrueCam manual to the input field in the dialog box.

**TrueCam M9 GPS 2.5K Quick Start Guide**

PC Player registration number: **SYZNU95Q3S**

**DVPlayer**

Please enter your registration code:

Your Email:

(You can retrieve the forgotten registration code through this email)

Validte Registration Code

18 33 KM/H N:50.1

MaxSpeed:87 KM/h X: 0.00  
AveSpeed:55 KM/h Y: 0.00  
Distance:2.77 KM Z: 0.00

MaxSpeed:254 KM/h AveSpeed:97 KM/h

